

Dosierparameter ändern

Die u.a. Dosierparameter lassen sich über die Slider oder durch direkte Eingabe verändern. Möchten Sie auf den werkseitig eingestellten Wert zurückkommen, dann drücken Sie einfach auf die blau beschrifteten Bezeichnungen.

Zur Eingabe drücken Sie auf das Tastenfeld.

The screenshot shows a mobile application interface for dosing control. At the top, it displays 'Soll' (setpoint) as 0 and 'Ist' (actual) as 0.00. Below this, it indicates 'Pulverauswahl: -PWD= mid' and 'verbunden mit [A&D FX120]'. The main control area features a 'Target>>>' field with the value 0, a 'Set' button, and a numeric keypad. Below the target field are five sliders for 'StopMassFill', 'Start Slow', 'LowSpeed', 'Toleranz', and 'Dämpfung'. At the bottom, there are toggle switches for 'Dual Mode', 'Full -Automatic', and 'Auto Tara', along with buttons for 'Tara', 'System Reset', 'System entleeren', and 'Scann Load'.

Slider

Zur Werkseinstellung

Tastenfeld

Parameter	Value	Adjustment
StopMassFill	3.00	+1 -1
Start Slow	2.5	
LowSpeed	50.00	-5 +5
Toleranz	0.04	<
Dämpfung	0.02	>

Dosierparameter ändern

Nach Betätigung des Tastenfeldes erscheint das Menu zur manuelle Eingabe der Dosierparameter.

The screenshot shows a mobile application interface with a black status bar at the top displaying the time 16:31, a signal strength indicator, and a battery level of 18%. Below the status bar is a green header bar with the text "Manuelle Parametereingabe" and a back arrow icon. The main content area is a light gray background with five rows of parameter settings. Each row consists of a label, a range, and a value. The values are displayed in green boxes.

Parameter	Range	Value
StopMass Fill ?	1.00.....15	3.00
Start Slow ?	0.50.....5.00	2.5
Slow Speed ?	10.....99	50.00
Toleranz ?	0.01.....0.50	0.04
Dämpfung ?	0.00.....0.30	0.02